

MC51

Mobile Computer

Accessories Guide



Standard

Adapters



PWR-18W-CN



PWR-18W-EU



PWR-18W-UK



PWR-18W-US

Adapter (CN/EU/UK/US), I/P: 100-240V, O/P: 5V3A/12V1.5A/9V2A, use with DC-BK-TypeC cable.

USB Cable



DC-BK-TypeC
1.0 meter Type-C cable.

Battery



BTRY-C51-50MA
Main battery, 5000mAh Li-on battery, Rated Voltage: 3.85V.

Optional

Charging Cradles



CRD-C50-RBC
Single Charging Cradle, DC port, charge device only, use with DCPWR-12V2A-XX adapter.



CRD-C50-SCC
Single Charging Cradle, Type-C port, charge device only, use with 10W/18W adapter.



CRD-C51-MBC
Charging Cradle for main battery, up to 4 slots, use with DCPWR-12V2A-XX adapter.



CRD-C51-DBC
Single Charging Cradle, Type-C port, charge MC50 device with spare battery. use with PWR-18W-XX adapter.



CRD-C50-DP
Charging Cradle for device, include the cradle cup(CRD-C50-INS),support device with UHF pistol grip or only device, use with DCPWR-12V2A-XX adapter. The cradle cup has an insert that must be removed prior to inserting the MC50 with UHF pistol.

Pistol Grip



RB-C50-PS
Snap-On Trigger Handle and Rugged Boot Kit without battery.

Hand Strap



RB-C51-HS
Hand Strap with buckle
This include 2 pcs screws,1 pcs wrist strap Buckle and 1 pcs hand strap.

Rugged Rubber Boot



RB-C50-RR
RB-C50-RR does not support charging cradle.

Pistol Battery



BYT-C50-PB
Pistol Battery for UHF Back Clip, 5200 mAh

Screen Protector



SP-C50
Tempered glass screen protector.

Adapters



DCPWR-12V2A-CN/UK/EU/US
Adapter (CN/EU/UK/US), I/P:100-240V, Pistol O/P:12V2A, DC